

PCE Kraftmessdose

The PCE load cell is a dynamometer controlled by a microprocessor and driven by battery. You can read traction and pressure forces from the screen. The actual load cell is mounted on a 2m long cable. Data can be transferred to a PC by its RS 232 interface.

